



American Quality, Value
& Service Since 1980

Recovery Tank Rinse Procedure



- Drain the Recovery Tank in accordance with local laws.
- Connect a Supply Hose (garden hose) to the Rinse System Inlet Valve.
- Turn water on at the faucet.
- Open Recovery Tank Drain Valve.
- Open the Rinse System Inlet Valve.
- Allow the Recovery Tank Rinse System to rinse/flush the tank out for the desired amount of time, usually 3 to 5 minutes.

NOTE: To flush the bottom of the tank more thoroughly, close the Drain Valve and allow the Recovery Tank to fill with a few inches of water and reopen the valve.

Important: Do not allow the Rinse System to fill the Recovery Tank, as it will overflow the tank.

- Once Rinse Procedure has been completed:
- Turn water off at the faucet.
- Close the Rinse System Inlet Valve.
- Disconnect the Supply Hose (garden hose).
- Once remaining water has been drained from the Recovery Tank, close the Drain Valve.

Please call us at **800.535.5025** or visit our website
butlersystem.com for more information.

